

Verde Bunker Liner



Verde Bunker Liner is a white artificial grass which has been developed specifically to hold Bunker Sand in place. The grass is made from a coarse polypropylene fibrillated yarn. This construction ensures the artificial grass remains upright which helps to retain the bunker sand even up the vertical walls of the bunker.

Verde Bunker Liner is designed to prevent & suppress vermin damage as well as reducing stone, silt & clay contamination. The artificial grass has a draining latex backing allowing rain water to pass through easily. The bunker liner has a 20mm open pile and is typically supplied in 25.00m x 4.00m rolls (100sqm)

The bunker liner is designed to create the playing characteristics of a natural bunker, deadening the golf ball when it lands & preventing it from bouncing back onto the green. Should the sand levels thin, the white tips of the grass discreetly alert the staff more sand is needed but still allows a shot to be played ensuring play isn't disrupted while the sand is topped up.

✓ **TRIED**

✓ **TESTED**

✓ **PROVEN**

Installation

Remove mud or soil from the existing bunker to a depth of around 100mm. You may need to remove more turf at this point if there are existing drainage problems.

Following the turf removal, re-establish levels using a crushed aggregate stone of 25mm to dust. This will need to be compacted.

Roll out the Bunker Liner, white side up so it covers the compacted base. Make sure there are no creases or bumps in the grass to ensure a smooth finish. Allow the bunker liner to rest up the sides of the bunker leaving a drainage channel at the top. Depending on the shape or size of the bunker, more than one roll may be required.

Trim the Bunker Liner by cutting from the back side with a sharp Stanley knife & straight edge. Try to avoid cutting across the picks where possible to prevent fraying and ensure a neater join. If more than one piece is required ensure the grass is pulled tight and all edges are trimmed neatly prior to making the join.

Whilst fitting the Bunker Liner make sure you leave a drainage channel around the perimeter. If your bunker requires a join you can use our jointing tape & adhesive. The jointing tape should be shiny side down which prevents any water from penetrating through the tape. You will need to weigh down the joins for 24 hours to allow a full cure.

Once the seams are secure, fill the bunker with sand. Ensure the tips of the grass are hidden beneath the surface. You may need to re-dress once the sand and liner has settled.



Advantages of Verde Bunker Liner

- ✓ Deadens ball bounce
- ✓ Saves time & money on labour
- ✓ Minimises sand replacement
- ✓ Reduces contamination
- ✓ Keeps vermin at bay
- ✓ Discreetly highlights low spots